



Technical Service Bulletin

May 1998 TSB103.02

General Storage Procedures for Polyvinyl Derivative (PVD) RO Membrane Elements

This bulletin provides guidelines for storing Hydranautics' Polyvinyl Derivative (PVD) Reverse Osmosis (RO) membrane elements.

Note: Before undertaking any long-term or short-term storage operation, contact Hydranautics for specific instructions related to the local environment.

Scope

The general storage procedures included in this bulletin are as follows:

1. Short-term storage of RO membrane elements in place in pressure tubes.
2. Long-term storage of RO membrane elements in place in pressure tubes.

Short-Term Storage

Short-term storage is for periods where an RO plant must remain out of operation for more than five days, but fewer than thirty days, with the RO elements in place. Prepare each RO train as follows:

1. Flush the RO section with feedwater, while simultaneously venting any gas from the system.
2. When the pressure tubes are filled, close the appropriate valves to prevent air from entering the system.
3. Reflush as described above at 5-day intervals.

Long-Term Storage

Long-term storage is for periods where an RO plant must remain out of operation for more than thirty days with the RO elements in place. Prepare each RO train as follows:

1. Clean the RO membrane elements in place.
2. Flush the RO section with a solution of permeate that contains an appropriate, approved biocide.
3. When the RO section is filled with this solution (make sure that it is completely filled), close the valves to retain the solution in the RO section.
4. Repeat Steps 2 and 3 with fresh solution every thirty days if the temperature is below 80°F (27°C), or every five days if the temperature is above 80°F (27°C).
5. When the RO system is ready to be returned to service, flush the system for approximately one hour using low-pressure feedwater with the product dump valve open to drain; then flush it at high pressure for 5 to 10 minutes with the product dump valve open to drain. Before returning the RO system to service, check for any residual biocide in the product.

Dry Storage

When RO elements are stored prior to installation or in transit to the plant site, they should be protected from direct sunlight and stored in a cool, dry place with an ambient temperature range of 68°F to 95°F (20°C to 35°C).